



# Daylight Raider


## Folding instructions




1. Take a rectangular A4 sheet of paper and fold it longways down the centre.
2. Open it out afterwards.




3. Take the first 1 cm of the rectangular sheet and fold it down. Then make successive folds as shown.



4. Fold the flap over and over until almost half the length of the sheet is folded in this concertina fashion. This will give a heavy and thick front lip.



5. Now fold along the diagonal dotted lines, bringing the top edges to the centre dotted line.



6. Fold along the centre line to create a side view like this. Mark a dotted line as shown.



7. Fold the wings down along the dotted line either side of the centre.

Your Daylight Raider should now look like this.



## Launching instructions

Hold your Raider about 4 cm from the nose and throw it gently with an overarm action. Indoors the Daylight Raider flies fast and accurately to its destination.

If you want the plane to circle, bend one wing slightly higher at the back. It will then circle with the lower wing towards the circle's centre.

**Safety first:** The glider has a sharp point. It should not be directed at a person's face.